



FRI	EUR	LUX	GO	PO
•	•	•	•	•
•	•	•	•	•
•	•	•	•	•
L	K	J	I	H
G	F	E	D	C
B	A			

GAMMES COUVERTES	
P O	520 kHz - 1620 kHz Acc 1620 kHz
G O	150 kHz - 264 kHz Acc 165 - 245 kHz
EUR	182 kHz
FRI	164 kHz
LUX	233 kHz

SCHÉMA DE PRINCIPE